



- 1** Begin the installation process by removing the (4) galvanized footplates **A** on the workbench.
- 2** Next, install the caster channels **B** to the legs with screws **C** and nuts **D**
- 3** Assembly the casters **E** to the unit using fender washers **F** and nuts **G** provided.
- 4** Lastly, unbolt and swap each (4) bolt stinger with the (8) bolt version supplied.
- 5** This completes the installation of the new caster kits onto a Borroughs workbench. Please see below for workbench configuration load ratings:

Current Mobile Workbench w/ Stringer only

- Maximum equally displaced work surface load of 1,000Lbs.
- Maximum work surface height of 37in.
- Design requires two (2) 8-Bolt Stringers

Current Mobile Workbench w/ Stringer & Bottom Shelf

- Maximum equally displaced work surface load of 750Lbs.
- Maximum work surface height of 37in.
- Design requires one (1) 8-Bolt Stringer & (1) Bottom Shelf